

Dry Cell operation**All ABS Body, sturdy yet light weight****Built –in Siren****Clear sound, long range & efficient design****Conveniently located Volume Control & Switch****10 Seconds Voice Recording Function****SPECIFICATIONS**

Power Output: 25w Max

Voice Range: 0.7 km

Power Source: 8 x UM-1 Cells

Working Voltage: DC 12v

Battery Life: 8-10 hrs.

Microphone: Unidirectional

Dimensions: Horn Dia.230mm, Length350mm

Weight: 1.5 kg without cells

OPERATION

Open the Back Cover. Remove the plastic battery sleeve and insert 8 nos. UM-1 cells with correct polarity, insert the sleeve into the battery compartment according to the instructions in the compartment. Then close the back cover until it locks. Now your megaphone is ready for action.

To activate the megaphone, press the Button on the grip when holding it in the hand after fixing the hanger inlet to the Mic fixing hanger or switch the button to ON when carrying it on the shoulder.

When using the megaphone, place your lips as close as possible to the megaphone on the hanger inlet. Adjust the Volume Control to the desired level without causing any howling or feedback.

Switch the button to ON, and press the SIREN button to activate emergency siren. To turn off the siren, switch back the same button to OFF or press the SIREN button again. .

Before recording, switch the button to ON, and press the REC button, then the REC indicator light is on. Now the recording function is ready. Speak to the microphone on the hanger inlet to record. To finish or stop the recording, just press the REC button again. The MAX recording time is 10 seconds.

To play the music or voice you recorded circularly, press the PLAY button. To stop, press PLAY button again.

If you have finished the megaphone ,you must switch the button to OFF.

PRECAUTIONS

Ensure correct polarity of Cells.

When the megaphone is not in use for a long period, remove the dry cells.

Drained cells will not give sufficient sound volume.

Replace cells at regular intervals, for optimum result.

If you have finished the megaphone ,you must switch the button to OFF.